



PANERAI

Istruzioni/Instructions

PANERAI



(A) LEVER (B) WINDING CROWN (C) HOURS (D) MINUTES (E) SMALL SECONDS*

*AVAILABLE ON SOME MODELS ONLY.
PICTURES SHOWN ARE FOR ILLUSTRATION PURPOSE ONLY. ACTUAL PRODUCTS MAY VARY.

INSTRUCTIONS FOR USE

WINDING THE WATCH

1. Raise the lever **(A)** of the crown cap to release the winding crown **(B)**.
For Radiomir models, unscrew the winding crown **(B)**.
2. Without pulling it out **(position 0)**, wind it clockwise (a) until you feel a blockage for a full winding.
3. Lock the winding crown by closing the lever **(A)** (for Radiomir models, screw it again) to ensure waterproofness.

Note: Turning the crown **(B)** counterclockwise **(b)** has no effect.

When fully wound, the watch ensures 3 days of power reserve for P.6000 calibers and 8 days for P.5000 calibers.

SETTING THE TIME

1. Raise the lever **(A)** of the crown cap to release the winding crown **(B)**.
For Radiomir models, unscrew the winding crown **(B)**.
 2. Pull it out to the first click **(position 1)** and set the time.
 3. Return the winding crown **(B)** to the initial position **(position 0)** and lock the lever **(A)** (for Radiomir models, screw it again).
-

PANERAI

©2024 Officine Panerai AG

Officine Panerai Marketing & Comunicazione
Viale Monza, 259 - 20126 Milano - Italy
www.panerai.com

panerai.com