

**GIRARD-PERREGAUX**



USER MANUAL

MINUTE REPEATER TRI-AXIAL TOURBILLON

# INSTRUCTIONS FOR USE

## WINDING

Crown in two positions:

0. Manual-winding position (crown not pulled out).
1. Time setting position (crown fully pulled out).

Manual-winding:

Your watch requires regular winding to work normally.

To wind, turn the crown backward and forward when it is in position 0). When fully wound, your watch has a power reserve of approximately 64 hours.

**Warning:** do not force the crown once the resistance increases as this could damage the movement.

## SETTING THE TIME

**Warning:** before making any manipulation, make sure the striking mechanism is disengaged.

1. Pull your crown out to the time setting position 1).
2. Turn your crown clockwise to position the hour and minute hands at the selected time. At the time signal, push the crown back to position 0). Your watch will restart immediately.

**Warning:** after making any setting, always return the crown to its original position, to preserve the water resistance of your watch and prevent any damage to the mechanism. To do so, press the crown against the case in position 0).

## STRIKING MECHANISM

Move the sliding device c) on the left-hand side of the case up to the banking and then release it. This will activate the striking mechanism, which will then strike the hours, quarters and minutes.

**Warning:** never change the time when the striking mechanism is engaged.



## FUNCTIONS

- a | Hours
- b | Minutes
- c | Minute repeater slide
- d | Tri-axial tourbillon

## GIRARD-PERREGAUX GP09560 HAND-WOUND MECHANICAL MOVEMENT

Diameter:	36.60 mm (1 1/4"')
Height:	17.32 mm
Frequency:	21,600 Vib/h - (3 Hz)
Jewels:	54
Power reserve:	minimum 64 hours
Functions:	tri-axial tourbillon, minute repeater, hours, minutes

## CASE

Diameter:	48.00 mm
Crystal:	sapphire anti-reflective 'box'
Case-back:	sapphire crystal 'box'
Water resistance:	30 meters (3 ATM)

MDE-0080